



MOBILE SOLUTIONS

ROUTER

CONFIGURATION

Technical Guide

Version # 7.4 Rev1



Prepared By:
Elliott Data Systems, Inc.

17825 Edison Ave
Chesterfield, MO 63005
(636) 386-8400
Fax (636) 386-3072

Customer Service Support
1-888-345-8511

mobilesolutions@elliottdata.com
www.elliottmobilesolutions.com

Table of Contents

| | |
|---------------------------------|----|
| Configure Wireless Router | 4 |
| Basic Settings..... | 4 |
| Lan..... | 4 |
| Wireless | 4 |
| Engenius | 5 |
| System Settings..... | 6 |
| Wireless settings..... | 7 |
| LAN Settings..... | 8 |
| ASUS RT-N10P..... | 9 |
| Wireless Setting..... | 11 |
| System Setting..... | 13 |

Configure Wireless Router

Note: Router is to only be used for wireless handheld devices.

Basic Settings

Leave or set router password to routers default password.

Usually User **Name: admin Password: admin**

Lan

Set IP to 192.168.2.1

Enable DHCP

DHCP Range 192.168.100 – 200

Wireless

Set SSID to the EEMS Case Name provide on configuration sheet

Se Encryption to **WEP or Shared**

Set key to “**a1b2c3d4e5**”

Engenius

1. Ensure both PC and handheld device(s) are on same wireless network/subnet.
2. Open **Internet Explorer** and enter **192.168.0.1** in the address bar and press **enter**.

(Factory router IP: 192.168.0.1)

You will be taken to the Router login prompt.

Enter user name: admin password: admin



Engenius[®]


THE LEADER IN LONG RANGE WIRELESS

Username


Password

Login Cancel


System Settings



Under "System" settings





Wireless settings



Set SSID to the case name provided on the install instructions.

Passphrase: a1b2c3d4e5






LAN Settings


Change the IP address to: 192.168.2.1

DHCP range: 192.168.2.100 - 200




Note: You will have to change IP on case/PC to same subnet of router (192.168.2.2)


ASUS RT-N10P




Click on this balloon or Browse to 192.168.1.1



A wizard will run. Select **Go**.



Select Manual Setting



Router requires you to change router during setup. Set to default setting

User: **admin** Password: **admin**




Click **Home Button**




Click **OK**

Wireless Setting




Set the SSID to the case name provide in the install sheet

Click **Apply**



Click Next




Change the Authentication to Open

Enter WEP Key : a1b2c3d4e5


Click Apply

System Setting



Click the LAN button and change the IP to **192.168.2.1** mask **255.255.255.0**


Click **Apply**



Router will reset




After router resets login **admin/admin**



Click on Lan

Set DHCP Server ip Range to 192.168.2.100-200



Scroll down and click Apply