

INSTALLATION NOTICE

- Dura-Plast Frame Systems must be shimmed and fastened with screws in five places along each vertical jamb, and one place in the middle of the horizontal header jamb.
 - On the hinge jamb, shims and screws that are long enough to penetrate in the stud must be placed in the middle hole of the three hinges and between the hinges, underneath the weatherstrip.
 - On the opposite jamb, shim and screw directly across from the five places on the hinge jamb. This is essential for the door frame system to remain straight and function properly.

Note: Screws must be used for fastening the door frame to the structural framing of the rough opening. **Nails are not recommended.**

- Place all screws behind the weather strip with the exception of the hinge screws. The hinge screws should be placed in the hinge holes closest to the weather strip.
- **DO NOT** anchor the door unit through the brickmould.
- Please refer to local building codes for additional reinforcement requirements.

