



General Instructions for Pronto Extra Wetter

1. Read and understand the [safety data sheet](#) (SDS) before using this product.
2. Apply Pronto Extra Wetter after mastic has been satisfactorily removed.
3. Mix 50-100 parts water to 1 part product in a low pressure spray applicator. Use a coarse spray and do NOT atomize.
4. Spray onto all surfaces until thoroughly wetted.
5. Reapply when surfaces start to dry. Coverage and reapplication intervals will depend on surface characteristics, temperature, and humidity.



TWIN CHEMICALS, INC.
6175 Hickory Flat Highway, Suite 110-344, Canton, GA, 30115
(800) 442-4958 / (770) 924-6147 Fax
www.twinchemicals.com
©2016 Twin Chemicals, Inc.

