



General Instructions for Pronto Locktite

1. Read and understand the [safety data sheet](#) (SDS) before using this product.
2. Apply Pronto Locktite after mastic has been satisfactorily removed and the surface has dried a minimum of 24-36 hours.
3. Use full strength in an airless sprayer. Mist all surfaces to lock down loose asbestos fibers on all fireproof insulation, protective
4. Barriers and ground/floor areas.
5. When dry the Pronto Locktite will be tacky to the touch.



TWIN CHEMICALS, INC.
6175 Hickory Flat Highway, Suite 110-344, Canton, GA, 30115
(800) 442-4958 / (770) 924-6147 Fax
www.twinchemicals.com
©2016 Twin Chemicals, Inc.

