

# YOU ASKED FOR A FASTER BOILERLESS STEAMER

## WE LISTENED



The **Evolution™ Boilerless Steamer** features **PowerPlate™** technology, which allows you to select from

### 3 different cook modes!

**PowerSteam™ Mode** - The fastest boilerless cook times.

**À la Carte Mode** - Still less than 1 gallon of water per hour and energy efficient with faster cook times.

**Batch Mode** - Excellent for Batch cooking.  
Maximum Water & Energy Efficiency.



### How to Adjust Performance Modes

Tools Required:  
7/16" wrench or 7/16"  
socket wrench or  
adjustable wrench



#### PowerSteam™ Mode

Remove the acorn nut and lock washer. Remove the PowerPlate™ from the mounting stud. Rotate plate so that the large rear vent is not covered by the plate. Slide the PowerPlate™ onto the stud and install the lock washer then the acorn nut and tighten.



#### À la Carte Mode

Remove the acorn nut and lock washer. Remove the PowerPlate™ and flip it so the larger hole is lined up over the large vent hole. Slide the PowerPlate™ onto the stud and install the lock washer then the acorn nut and tighten.



#### Batch Mode

Leave as received from the factory.

**A**ccutemp  
accutemp.net (800) 210-5907

WORLD'S BEST  
**EVOLUTION**  
BOILER-FREE STEAMER