

Air Compressor part breakdown sheet - IH1041L

| Item | Description           | Part    | Item | Description              | Part         |
|------|-----------------------|---------|------|--------------------------|--------------|
| 1    | Head Bolt M6x55       | IH30551 | 38   | Capacitor                | IH2250       |
| 2    | Spring washer 6       | IH1211  | 39   | Washer 3                 | IH1039       |
| 3    | Cylinder head         | IH1343  | 40   | Spring washer 3          | IH1040       |
| 4    | Exhaust elbow         | IH1086  | 41   | Bolt M3*6                | IH1041       |
| 5    | Head gasket           | IH1051  | 42   | Shroud                   | IH2024       |
| 6    | Valve assembly        |         | 43   | Bolt M5*15               | IH1727       |
| 7    | Valve seat/cyl gasket | IH1053  | 44   | Bolt M8*55               | IH2211       |
| 8    | Cylinder              | IH2034B | 45   | Washer 8                 | IH2212       |
| 9    | Piston                | IH2038B | 46   | Nut 8                    | IH2213       |
| 10   | Piston air ring       | IH2039M | 47   | Pressure switch          | 21UCBDB-CH   |
| 11   | Piston oil ring       | IH2039N | 48   | Connector                | IH0003       |
| 12   | Piston pin clip       | IH1420B | 49   | Regulator                | R46-200-RNLA |
| 13   | Piston pin            | IH1534B | 50   | Connector                | IH0004       |
| 14   | Connecting rod        | IH1066B | 51   | Pressure gauge           | IH1177       |
| 15   | Cyl/Crankcase gasket  | IH1225  | 52   | Plug                     | IH1360       |
| 16   | Bolt M8*25            | IH2035  | 53   | Quick connect            | 10TT-8       |
| 17   | Spring washer 8       | IH1212  | 54   | Strain relief            | IH2206       |
| 18   | Crankshaft            | IH1068A | 55   | Power cord               | IH1841       |
| 19   | Bolt M8*22-LH         | IH1802  | 56   | Terminal (O)             |              |
| 20   | Crank case gasket     | IH2019  | 57   | Terminal (Y)             |              |
| 21   | Crank case cover      | IH2021  | 58   | Handle grip              | IH1527       |
| 21a  | Bolt M6*10            | IH2207  | 59   | Tank                     | IH2050       |
| 22   | Seal                  | IH1591  | 60   | Custion foot             | IH2200       |
| 23   | Oil sight glass       | IH1519  | 61   | Washer 6                 | IH2202       |
| 24   | Bolt M6*18            | IH0621  | 62   | Bolt                     | IH2203       |
| 25   | Breather              | IH1071  | 63   | Check valve              | IH2026A      |
| 26   | Crank case            | IH2020  | 64   | Safety valve             | IH1090       |
| 27   | Oil seal              | IH0530  | 65   | Drain valve              | IH1850       |
| 28   | Bearing               | IH0140  | 66   | Tube                     | IH1302       |
| 29   | Rotator               | IH1919  | 67   | Unloader tube w/fitting  | IH1302       |
| 30   | Rear bearing          | IH0150  | 68   | Air filter assembly      | IH1072       |
| 31   | Stator                | IH1918A | 69   | Discharge tube w/fitting | IH1170       |
| 32   | Spring washer wave    | IH2209  | 71   | Air filter assembly      | IH1072       |
| 33   | Rear cap              | IH1046  | 72   | Overload Protector       | IH2000       |
| 34   | Spring washer 5       | IH2210  | 6a   | Valve Plate              | ih1064       |
| 35   | Bolt M5               | IH1048  | 6b   | Reed Valve               | IH1052       |
| 36   | Fan                   | IH1044  | 6c   | Middle Valve Gst         |              |
| 37   | Circlips              | IH1101  |      |                          |              |



# IRON HORSE

**WOOD**  
INDUSTRIES  
INCORPORATED

Call 1-800-551-2406 for the Customer Service Department.

REVISED 3/24/17

