

OWNER'S MANUAL FILTRATION STRAW Radiological Filter

The most field and laboratory tested product of its kind.

This portable Micro-Filtration System is the answer to today's need for safe and accessible drinking water at home and on the go.

The Radiological filter is perfect for everyday use, as well as for emergency preparedness and radiological contamination. This filtration straw is cost-effective, easy to use, and produces up to 25 gallons of great-tasting filtered water.

USE AND CARE

In case of a radiological emergency, follow all government recommendations.

FLUSH PRIOR TO FIRST USE.

FLUSHING INSTRUCTIONS

1. Remove straw from package.
2. Remove light blue cap over mouthpiece and top of straw.
3. Press small side of bulb over mouthpiece.
4. Twist open opposite end of straw. (Does not detach.)
5. Attach larger side of bulb to faucet for flushing.
6. Turn faucet on low for 2 minutes and allow water to run through the rubber bulb and flush the straw filter.
7. Turn water off and detach the rubber bulb from faucet and mouthpiece.

Your straw is now ready for use!

- DO NOT put in freezer.
- DO NOT use with hot water.
- DO NOT use with salt water.
- DO NOT use with anything but water.
- DO NOT put in dishwasher.



STORAGE AND MAINTENANCE

STORAGE

1. Blow through mouthpiece of straw to remove excess water.
2. Twist opposite end of straw close.
3. Replace cap on mouthpiece.

MAINTENANCE

Plastic parts can be cleaned with a mild liquid detergent.

Regular flushing of straw is recommended when there is a restriction of water flow, or when a change in taste of water is detected. If low water flow and change in taste of water remains, a replacement filter is recommended.

ALL PLASTICS ARE FDA FOOD GRADE APPROVED, BPA-FREE, AND NON- LEACHING.

Exclusive filter is tested by EPA and state registered laboratories and meets or exceeds EPA/ANSI protocols/methodology, and NSF Standards 42 and 53 by Broward Testing Laboratory.

FILTER MADE IN USA

CONTAMINANT REDUCTION AND REMOVAL

The exclusive Ionic-Adsorption Micro-Filtration System eliminates or reduces up to 99.99% of the following water contaminants:

Aesthetic contaminants:
unpleasant taste and odors, cloudiness, silt, sediment, chlorine, and chlorine by-products

Chemical contaminants:
toxic chemicals (VOCs), trihalomethanes, PCBs, PCEs, detergents, and pesticides

Dissolved solid contaminants:
arsenic, lead, mercury, copper, zinc, aluminum, chromium 6, and fluoride up to 90%

Radiological contaminants:
gross beta, radon 222, alpha radium 226, uranium, plutonium, cesium 134 and 137

90-DAY GUARANTEE

Manufacturer warrants the portable water filtration system to the consumer for a period of 90 days from the date of purchase, when used in accordance with the manufacturer's instructions. If there are any defects with the product, return the unit, postage paid, to the distributor with a valid purchase receipt. This guarantee does not cover improper use, or maintenance or premature clogging by overly turbid water. This warranty gives the consumer specific rights. Manufacturer shall, under no circumstances, be liable for any special, indirect or consequential damages owing to misuse of goods. Manufacturer makes no warranty of fitness or merchant-ability and no other warranty, oral or written, expressed or implied except as specifically set forth herein.